



MR F80B EU- ATIS ID PROGRAMMING

MR F80 ATIS ID Programming:

In some European country's¹ inland waterways, the use of the Automatic Transmission Identification System (**ATIS**) feature of this Cobra radios is required to identify marine vessels. An **ATIS** ID number is required to operate the **ATIS** feature. The **ATIS** ID number is derived from your vessels call sign. You or your dealer must enter your **ATIS** ID number into this radio before the **ATIS** system will become functional. Please consult your local dealer for questions about local **ATIS** requirements.

With this feature activated, the vessels **ATIS** ID number (station) is transmitted after every push of the **Talk** button. Power is limited to 1 W maximum when **ATIS** is activated.² If the MR F80B EU is used on the inland waterways of the contacting governments of the *Regional Arrangement Concerning the Radiotelephone Service on Inland Waterways* (also known as the Basel Agreement), then ATIS must be turned on and an ATIS ID programmed when operating in the applicable waterways. ATIS operation can be turned ON or OFF as needed using the MR F80B EU's Setup menu.

Notes:

1. The Basel Agreement includes the following countries: Germany, Austria, Belgium, Bulgaria, Croatia, France, Hungary, Luxembourg, Moldova, The Netherlands, Poland, Romania, Russian Federation, The Slovak Republic, Switzerland, The Czech Republic, Ukraine and The Federal Republic of Yugoslavia.
2. When ATIS is enabled, certain programming steps have been implemented to protect the integrity of the Basel Agreement, including **blocking DSC** functions when ATIS is turned ON. ATIS can be turned ON and OFF in the **Setup** menu.
- 3.) You only have **one(1) attempt to set the ATIS ID** number. Once this number has been entered, only your Cobra distributor with proprietary PC software can reset the **ATIS ID** number. You can also return the radio to Cobra for reprogramming.

To enter the **ATIS** ID number:

- 1) Enter the **Setup** menu and scroll to **ATIS** menu
- 2) With selection arrow pointing to **ATIS** press **ENTER**
- 3) Position selection arrow to ON and press **ENTER**
- 4) Position selection arrow to **ATISMMSI** and press **ENTER**
- 5) Rotate the **Channel Select** knob or the microphone **Channel Up/Down** to select numeric characters
- 6) Press **Function (F1/F2)** to backspace/ advance characters
- 7) Press the **Enter** button when all 10 digits are entered.
- 8) When the entry is complete, exit the **ATIS** menu and return to the **Setup** or press **ESC** to directly go to standby.

