

# Élan



- Quick start guide
- Kurzreferenz
- Aide-mémoire
- Guida rapida
- Guía rápida
- Vlugge gids
- Snabbguide
- Lynvejledning

12F44

**1 Aerial - Antenne - Antenne - Antenna - Antena - Antenne - Antenn - Antenne**

A hand is shown pulling the telescopic antenna upwards from the top of the radio's carrying handle.

**2 Power - Stromversorgung - Alimentation - Alimentazione - Alimentación - Strom - Ström - Power**

The diagram shows two power options. The top option shows a USB power source connected to the radio. The bottom option shows a battery compartment with an arrow pointing to it from the text 'X 6 size 'C''. Below this, a digital display shows 'PURE Élan' and a battery level indicator with a '~1 min' timer icon.

**3 Volume - Lautstärke - Volume - Volume - Volumen - Volume - Volym - Lydstyrke**

A hand is shown sliding the volume control slider to the right. The slider has '-' on the left and '+' on the right, with the word 'Volume' in the center.

**4 Station (DAB) - Sender - Station - Stazione - Emisora - Station - Station - Station**

The diagram shows two steps. In the first, a hand presses the 'Select' button on a slider. The display shows 'ST DAB 18:30 1Xtra - BBC \*Virgin'. In the second, the hand presses the '+' button. The display shows 'ST DAB 18:30 Virgin Radio oday's best musi'.


**5 Station (FM) - Sender - Station - Stazione - Emisora - Station - Station - Station**

The diagram shows three steps. In the first, a hand presses the 'DAB/FM' button. The display shows 'FM 87.50MHz'. In the second, a hand presses the '+' button on the slider. The display shows 'FM Searching...'. In the third, the display shows 'ST FM 98.20MHz'.

6

**Presets - Belegungen - Présélections - Memorie - Presintonias - Voorafinstellingen - Förinställda stationer - Presets**

1-4




18:30  
Virgin Radio  
Preset 1 saved

5-8



18:30  
BBC Radio 1  
Use preset 5-8



18:30  
BBC Radio 1  
Preset 5 saved

**Recall - Abrufen - Rappel - Richiama - Recordar - Heroproepen - Hämta - Genkald**

1-4




18:30  
Virgin Radio  
oday's best musi

5-8



18:30  
BBC 6 Music  
Use preset 5-8



18:30  
BBC Radio 1  
Lamacra Live with

7

**Info - Informationen - Info - Info - Información - Info - Info - Information**

Info



18:30  
1Xtra - BBC  
Bringing you hot

18:30  
1Xtra - BBC  
Other Music

18:30  
1Xtra - BBC  
BBC National DAB

18:30  
1Xtra - BBC  
18:30 27-08-2004

18:30  
1Xtra - BBC  
12B 225.64MHz

18:30  
1Xtra - BBC  
128kbps Stereo

18:30  
1Xtra - BBC  
Sig. quality 100

8

**Sleep - Einschlafen - Veille - Sleep - Desconexión - Slaap - Sleep - Sleep**

Sleep



22:06  
Classic FM  
Sleep 15



Sleep



22:06  
Classic FM  
Sleep 30



22:06  
Classic FM  
Sleep 90



22:07  
Classic FM  
stress-free mix

**Cancel - Löschen - Annulation - Annulla - Cancelar - Annuleer - Avbryt - Annuller**

Sleep



22:08  
Classic FM  
Remain 88

Sleep



22:08  
Classic FM  
Sleep off

22:08  
Classic FM  
on the internet

**Élan**

**PURE Digital**  
Imagination Technologies Ltd.,  
Imagination House,  
Home Park Estate,  
Kings Langley, Herts., WD4 8LZ, UK

**For support**  
Telephone: +44 (0) 1923 277477  
E-mail: support@pure.com  
Web: www.pure.com

**PURE**